

KYACB-Manual



KYLAND TECHNOLOGY CO., LTD.

Osborn.Liu

2023.01.13

1. Product information

<https://kyland.com/Products/KyACBUSBRJ45.html>

<https://kyland.com/Products/KyACBUSBM12.html>

2. Product photo

2.1 KyACBUSBRJ45



2.2 KyACBUSBM12



3. Product compatibility

Adapting for sicom3000A, sicom3000a-LITE, sicom3000S, sicom3448G,

sicom3024G, Aquam8012A

4. Use manual

Note: Before operating, you need let Kyacb connect to device.

4.1 Web operation

4.1.1 Auto Configuration

Auto Configuration

Please note: USB download/upload config file is startup-config.

Auto Configuration ☒ Disable ☐ Enable

After the state is enabled, the device automatically downloads the configuration file and takes effect when the device boots.

Note: Auto Configuration default is Disable.

Auto Configuration priority from USB.

1. MAC.CFG

2. Device type.CFG

3. Switch local config file

4.1.2 USB File List

Index	USB File List
1	000001
2	33A878.CFG
3	3000A.CFG

Note: when you upload file to USB, there will show your file.

4.1.3 File configuration

USB File name

To download or delete files, you need to enter the existing filename in the list of USB files.

Upload file does not need to enter the file name.

Note:

1. Upload file does not need to enter the file name, and directly click "configuration upload to USB" and "ram-log Upload to USB". There will be two files of config and one file of log when you have done.

2. Switch config file is named by MAC address and Device type, Switch log file

is named by MAC address.

3. Config file suffix must be **.CFG**. Log file suffix must be **.LOG**.
4. When you upload file to USB, if there is a same file, user can decide replacing it or not.
5. When you want to restore config from USB, only click “configuration download from USB” and reboot.

4.1.4 Save configuration

Save Running Configuration to startup-config

Please note: The generation of the configuration file may be time consuming, depending on the amount of non-default configuration.

Save Configuration

192.168.4.50 显示

startup-config saved successfully, Do you want startup-config upload to USB?

YES NO

Note: when you save configuration on web GUI, there will show a note to decide if upload to USB.

4.2 CLI-GUI operation

4.2.1 Auto Configuration

SWITCH(config)# usb auto backup configurator enable

Note: Auto Configuration default is Disable.

Auto Configuration priority from USB.

1. MAC.CFG

2. Device type.CFG

3. Switch local config file

4.2.2 Upload to USB

SWITCH(config)# usb config-file upload Configuration upload

SWITCH(config)# usb backup syslog upload Log upload

4.2.3 Download from USB

SWITCH(config)# usb config-file download file-name Configuration download

